



IRONCLAW RGB WIRELESS

WIRELESS RECHARGEABLE GAMING
MOUSE WITH SLIPSTREAM TECHNOLOGY

CHARGING THE MOUSE

IMPORTANT: The IRONCLAW RGB WIRELESS mouse must be fully charged before its first use. Connect the IRONCLAW RGB WIRELESS mouse to an available USB 2.0 or 3.0 port on your PC with the USB charging / data cable. The multi-purpose LED indicator on the mouse will begin pulsing green to denote battery charging and will turn solid when charging is complete. The battery has no "memory effect" and should not be completely discharged before recharging to ensure it will last for hundreds of charge / discharge cycles.

GETTING TO KNOW YOUR MOUSE



- A - LEFT CLICK BUTTON
- B - RIGHT CLICK BUTTON
- C - MIDDLE CLICK BUTTON
- D - PROFILE UP BUTTON
- E - PROFILE DOWN BUTTON
- F - DPI UP BUTTON
- G - DPI DOWN BUTTON
- H - FORWARD BUTTON
- I - BACKWARD BUTTON
- J - OPTION BUTTON
- K - MULTI-PURPOSE LED INDICATOR
- L - OPTICAL GAMING SENSOR
- M - PTFE GLIDE PADS
- N - POWER / WIRELESS MODE SWITCH
- O - USB WIRELESS RECEIVER
- P - USB CHARGING / DATA CABLE
- Q - USB CABLE ADAPTER

SETTING UP YOUR MOUSE USING 2.4GHz WIRELESS

- Turn on your computer and connect the USB wireless receiver to an available USB port.
- Toggle power / wireless mode switch to "2.4GHz" position to turn on your mouse.
- The multi-purpose LED indicator on your mouse will turn solid white when automatically connected.
- Download the iCUE software from www.corsair.com/downloads.
- Run the installer program and follow instructions for installation.

SETTING UP YOUR MOUSE USING BLUETOOTH®

- Turn on your Bluetooth 4.0 or higher enabled computer and initiate Bluetooth pairing mode on it.
- Hold PROFILE UP button and toggle power / wireless mode switch to BT position to turn on your mouse. The multi-purpose LED indicator will start blinking blue.
- The multi-purpose LED indicator on your mouse will turn solid blue when connected.

MULTI-PURPOSE LED INDICATOR

Various aspects of mouse operation are communicated through the multi-purpose LED indicator located on the left side of the mouse.

		MULTI-PURPOSE LED INDICATOR		
		LED #1	LED #2	LED #3
USB WIRELESS	BATTERY CHARGING	PULSING GREEN	OFF	OFF
	BATTERY CRITICAL, RECHARGE REQUIRED	PULSING RED	OFF	OFF
	BATTERY LOW, RECHARGE SOON	BLINKING RED	BLINKING RED	OFF
	BATTERY MEDIUM	BLINKING AMBER	BLINKING AMBER	OFF
	BATTERY HIGH	BLINKING GREEN	BLINKING GREEN	OFF
	BATTERY CHARGED	GREEN	GREEN	GREEN
2.4GHz WIRELESS	2.4GHz WIRELESS MODE - PAIRED	BLINKING WHITE		
	2.4GHz WIRELESS MODE - PAIRED	WHITE		
	2.4GHz WIRELESS MODE - PAIRING FAILED	PULSING WHITE		
	BT WIRELESS MODE - PAIRED	BLINKING BLUE		
	BT WIRELESS MODE - PAIRED	BLUE		
	BT WIRELESS MODE - PAIRING FAILED	PULSING BLUE		
BLUETOOTH	STATUS #1	CHGN	OFF	OFF
	STATUS #2	CHGN	CHGN	OFF
	STATUS #3	CHGN	CHGN	CHGN
SLIPSTREAM	PROFILE #1	RED	OFF	OFF
	PROFILE #2	OFF	GREEN	OFF
	PROFILE #3	OFF	OFF	BLUE

マウスの充電

重要: IRONCLAW RGB ワイヤレスマウスを最初にお使いいただく際は、完全に充電してください。
USB 充電 / データケーブルをお使いの PC の空いている USB 2.0 または 3.0 ポートに差し込んで、IRONCLAW RGB ワイヤレスマウスを接続します。マウスの多目的 LED インジケータが緑色に点滅すると、バッテリーが充電中であることを示します。充電が完了すると点滅が停止し、点灯します。
このバッテリーには「メモリ効果」はありません。したがって、長期間にわたって充電/放電サイクルを持續できるよう、完全に充電される前に満充電してください。

マウスについて



- A - セクリックボタン
- B - 右クリックボタン
- C - ミッドクリックボタン
- D - プロファイルアップボタン
- E - プロファイルダウンボタン
- F - DPI 増加ボタン
- G - DPI 減少ボタン
- H - フォワードボタン
- I - バックワードボタン
- J - オプションボタン
- K - 多目的 LED インジケータ
- L - 光学ゲーミングセンサー
- M - PTFE グライドパッド
- N - 電源 / ワイヤレスモードスイッチ
- O - USB ワイヤレスレシーバー
- P - USB 充電 / データケーブル
- Q - USB ケーブルアダプタ

2.4GHz 無線を使用したマウスのセットアップ

- コンピュータの電源を入れ、USB ワイヤレスレシーバーを PC の空いている USB ポートに差し込みます。
- 電源 / ワイヤレスモードスイッチを 2.4GHz の位置に切り替えて、マウスの電源を入れます。
- 自動的に接続されると、マウスの多目的 LED インジケータが緑色に点灯します。
- iCUE ソフトウェアを www.corsair.com/downloads からダウンロードします。
- インストーラプログラムを実行し、指示に従ってインストールを行います。

BLUETOOTH®を使用したマウスのセットアップ

- Bluetooth 4.0 以降に対応しているコンピュータで、Bluetooth ペアリングモードを起動します。
- プロファイルアップボタンを押しながら、電源 / ワイヤレスモードスイッチを BT の位置に切り替えて、マウスの電源を入れます。多目的 LED インジケータが青色に点滅し始めます。
- マウスの多目的 LED インジケータが青色に点滅すると、マウスのペアリングの準備が整ったことを示します。接続されると青色の点灯に変わります。

多目的 LED インジケータ

マウス操作のさまざまな面で、マウスの左側にある 多目的 LED インジケータが使用されます。

		多目的 LED インジケータ		
		LED #1	LED #2	LED #3
ワイヤレス	バッテリー充電中	緑 (パルス点滅)	OFF	OFF
	バッテリー切れ寸前 (満充電が必要)	赤 (パルス点滅)	OFF	OFF
	バッテリー低電圧 (すぐに満充電)	赤 (点滅)	赤 (点滅)	OFF
	バッテリー電圧は中	琥珀色 (点滅)	琥珀色 (点滅)	OFF
	バッテリー電圧は高	緑 (点滅)	緑 (点滅)	OFF
	バッテリー充電完了	緑	緑	緑
2.4GHz WIRELESS	2.4GHz ワイヤレスモード - ペアリング中	白 (点滅)		
	2.4GHz ワイヤレスモード - ペアリング済み	白		
	2.4GHz ワイヤレスモード - ペアリング失敗	白 (パルス点滅)		
	BT ワイヤレスモード - ペアリング中	青 (点滅)		
	BT ワイヤレスモード - ペアリング済み	青		
	BT ワイヤレスモード - ペアリング失敗	青 (パルス点滅)		
Bluetooth	ステータス #1	シアン	OFF	OFF
	ステータス #2	シアン	シアン	OFF
	ステータス #3	シアン	シアン	シアン
SLIPSTREAM	プロファイル #1	赤	OFF	OFF
	プロファイル #2	OFF	緑	OFF
	プロファイル #3	OFF	OFF	青