

User's Guide

EVGA H55 Motherboard

Table of Contents

| | |
|---|----|
| User's Guide | 1 |
| EVGA H55 Motherboard | 1 |
| Before You Begin... .. | 6 |
| Parts NOT in the Kit | 6 |
| EVGA H55 Motherboard | 7 |
| Motherboard Specifications..... | 7 |
| Hardware Installation | 9 |
| Safety Instructions..... | 9 |
| Preparing the Motherboard | 10 |
| Installing the CPU | 10 |
| Installing the CPU Fan | 11 |
| Installing System Memory (DIMMs) | 12 |
| Installing the Motherboard..... | 12 |
| Installing the I/O Shield | 13 |
| Securing the Motherboard into a System Case | 14 |
| Connecting Cables | 14 |
| 24-pin ATX Power (PW1)..... | 15 |
| 8-pin ATX 12V Power (PW12) | 15 |
| Connecting IDE Hard Disk Drives | 16 |
| Connecting Serial ATA Cables..... | 17 |
| Connecting Internal Headers | 18 |
| Front Panel Header | 18 |
| IEEE1394a (Firewire)..... | 19 |
| USB Headers | 20 |
| Audio | 21 |

| | |
|--|----|
| Expansion Slots | 22 |
| PCI Slots | 22 |
| PCI Express x16/x8/x4 Slots..... | 22 |
| Onboard Buttons | 23 |
| Clear CMOS Button | 23 |
| RESET and POWER Button | 23 |
| Post Port Debug LED and LED Status Indicators..... | 24 |
| Post Port Debug LED | 24 |
| LED Status Indicators | 24 |
| Configuring the BIOS | 25 |
| Enter BIOS Setup..... | 26 |
| Main Menu..... | 26 |
| Standard BIOS Features Menu..... | 28 |
| System Time / System Date..... | 29 |
| Advanced BIOS Features | 30 |
| IDE Configuration | 30 |
| Boot Settings Configuration | 31 |
| AHCI Configuration | 31 |
| USB Configuration | 31 |
| Advanced Chipset Features..... | 32 |
| North Bridge Configuration..... | 32 |
| PCI Express Configuration..... | 32 |
| PCI/PNP Resource Management | 34 |
| Clear NVRAM..... | 34 |
| Plug & Play O/S | 34 |
| PCI Latency Timer | 34 |
| Allocate IRQ to PCI VGA | 35 |
| Palette Snooping..... | 35 |

| | |
|---|----|
| PCI IDE BusMaster | 35 |
| OffBoard PCI/ISA IDE Card | 35 |
| Boot Configuration Features | 36 |
| Boot Device Priority..... | 36 |
| Hard Disk Drives | 36 |
| Power Management Features..... | 37 |
| ACPI Configuration | 37 |
| SLP_S4# Min. Assertion Width | 37 |
| Restore on AC Power Loss | 37 |
| Hardware Health Configure..... | 38 |
| H/W Health Function | 38 |
| CPU Fan Mode Setting | 38 |
| Frequency/Voltage Control Menu | 39 |
| Memory Configure..... | 39 |
| CPU Configuration | 39 |
| Installing Drivers and Software | 40 |
| Windows XP/Vista/7 Driver Installation | 40 |
| Appendix A. POST Codes for the EVGA H55 Motherboard | 41 |

List of Figures

| | | |
|------------|------------------------------------|----|
| Figure 1. | PW1 Motherboard Connector | 15 |
| Figure 2. | CMOS Setup Utility Main Menu | 27 |
| Figure 3. | Standard BIOS Features Menu | 28 |
| Figure 4. | Advanced BIOS Features | 30 |
| Figure 5. | Advanced Chipset Features | 32 |
| Figure 6. | PCI/PNP Resource Management | 34 |
| Figure 7. | Boot Configuration Features | 36 |
| Figure 8. | Power Management Features | 37 |
| Figure 9. | Hardware Health Configure | 38 |
| Figure 10. | Frequency/Voltage Control | 39 |

Before You Begin...

Parts NOT in the Kit

This kit contains all the hardware necessary to install and connect your new EVGA H55 Motherboard. However, it does not contain the following items that must be purchased separately to make the motherboard functional.

- ❑ **Intel Socket 1156 Processor**
- ❑ **DDR3 System Memory**
- ❑ **Socket 1156 or Socket 775 Cooling fan**
- ❑ **PCI Express or PCI Graphics Card**
- ❑ **Power Supply**

EVGA assumes you have purchased all the necessary parts needed to allow for proper system functionality. For a full list of supported CPU's on this motherboard, please visit <http://www.evga.com/support/motherboard/>.

When replacing a motherboard in a system case, you will need to reinstall an operating system even though the current hard disk may already have an operating system.

EVGA reserves the right to change product specifications without notice.

EVGA H55 Motherboard

Motherboard Specifications

- ❑ Size
ATX form factor of 12 inch x 9.6 inch
- ❑ Processor support
Intel Socket 1156 CPU's
- ❑ Operating systems:
Supports Windows XP 32bit/64bit, Windows Vista 32bit/64bit, and Windows 7 32bit/64bit
- ❑ Intel H55 Express Chipset
- ❑ System Display output interface
Supports D-SUB, DVI and DP (Display Port).
With Intel Core i3 CPU install support:
D-SUB: 2048 x 1536 @75 Hz
DVI: 1920 x 1200 @60Hz
DP: 2560 x 1600 @60Hz
- ❑ System Memory support
Supports triple channel DDR3-1333+. Officially supports up to 16GBs of DDR3 memory.
- ❑ USB 2.0 Ports
Supports hot plug
Twelve USB 2.0 ports (Eight rear panel ports, four onboard USB headers)
Supports wake-up from S1 and S3 mode
Supports USB 2.0 protocol up to a 480 Mbps transmission rate

- ❑ Eight(8) onboard Serial ATA II
300MBps data transfer rate
Two Serial ATA II connectors from JMicron's JMB363 with support for RAID 0, RAID 1
- ❑ Onboard LAN
Integrated LAN port's
Supports 10/100/1000 Mb/sec Ethernet
- ❑ Onboard IEEE1394a (Firewire)
Support hot plug
Two IEEE1394a ports (One rear panel port, one onboard 1394 header) with a rate transmission of 400 Mbps
- ❑ Onboard Audio
Realtek High-Definition audio
Supports 8-channel audio
Supports Jack-Sensing function
- ❑ Green Function
Supports ACPI (Advanced Configuration and Power Interface)
Supports S0 (normal), S1 (power on suspend), S3 (suspend to RAM), S4 (Suspend to disk - depends on OS), and S5 (soft - off)
- ❑ Expansion Slots
Three PCI slots
One PCI Express x4/x8/x16 slot
One PCI Express X4 slot
One DVI, one VGA, one display port support

Hardware Installation

This section will guide you through the installation of the motherboard. The topics covered in this section are:

- ❑ Preparing the motherboard
- ❑ Installing the CPU
- ❑ Installing the CPU fan
- ❑ Installing the memory
- ❑ Installing the motherboard
- ❑ Connecting cables

Safety Instructions

To reduce the risk of fire, electric shocks, and injury, always follow basic safety precautions.

Remember to remove power off your computer by disconnecting the AC main source before removing or installing any equipment from/to the computer chassis.

Preparing the Motherboard

Installing the CPU



Be very careful when handling the CPU. Hold the processor only by the edges and do not touch the contacts on the motherboard or CPU. **Any physical damage to the motherboard pins will void the warranty.**

Use the following procedure to install the CPU onto the motherboard:

Unhook the socket lever by pushing *down* and *away* from the socket.

Pull the socket lever back and the load plate will automatically lift. There is a protective socket cover within the CPU socket to protect the socket when there is no CPU installed.

Remove the protective socket cover from the CPU Socket in a straight up motion.



Note: It is a good idea to save the cover so that whenever you remove the CPU you have a safe place to store it.

Align the notches in the processor with the notches on the socket.


Lower the processor straight down into the socket without tilting or sliding it into the socket

Note: Make sure the CPU is fully seated and level.


Lower the load plate so it is resting on the CPU.

Pull back the socket lever again to ensure the load plate tip engages under the shoulder screw cap.

Carefully close and latch the lever.



Align notches with notches on the CPU



Load plate tip under screw cap

Installing the CPU Fan

There are many different fan types that can be used with this motherboard. Follow the instruction that came with you fan assembly. Be sure that the fan orientation is correct for your chassis type and your fan assembly.


Please note that there are 2 sets of mounting holes, the holes surrounded in white are to be used for Socket 1156 heatsinks and are labeled. The other holes are to be used for Socket 775 heatsinks.

In most cases, the Socket 1156 mounting holes will be used.

Installing System Memory (DIMMs)

Your new motherboard has four 240-pin slots for DDR3 memory. These slots support 256 MB, 512 MB, 1GB, 2GB, 4GB DDR3 technologies. There must be at least one memory bank populated to ensure normal operation. Use the following the recommendations for installing memory.

- ❑ **One DIMM:** If using 1 DIMM (**Single Channel**), install into: **DIMM slot 1.**
- ❑ **Two DIMMs:** If using 2 DIMMs (**Dual Channel**), install into: **DIMM slots 1 and 3.**
- ❑ **Four DIMMs:** If using 4 DIMMs (**Dual Channel**), install into: **DIMM slots 2, 1, 4, and 3.**



Use the following procedure to install memory DIMMs. Note that there is only one gap near the center of the DIMM slot. This slot matches the slot on the memory DIMM to ensure the component is installed properly.

1. Unlock a DIMM slot by pressing the module clips outward.
2. Align the memory module to the DIMM slot, and insert the module vertically into the DIMM slot. The plastic clips at both sides of the DIMM slot automatically lock the DIMM into the connector.

Installing the Motherboard

The sequence of installing the motherboard into a system case depends on the chassis you are using and if you are replacing an existing motherboard or working with an empty system case. Determine if it would be easier to make all the connections prior to this step or to secure the motherboard and then make all the connections. It is normally easier to secure the motherboard first.

Use the following procedure to install the I/O shield and secure the motherboard into the chassis.

Installing the I/O Shield

The motherboard kit comes with an I/O shield that is used to block radio frequency transmissions, protects internal components from dust and foreign objects, and promotes correct airflow within the chassis.

Before installing the motherboard, install the I/O shield from the *inside* of the chassis. Press the I/O shield into place and make sure it fits securely.

Securing the Motherboard into a System Case

Most system cases have a base with mounting studs or spacers to allow the motherboard to be secured to the chassis and help to prevent short circuits. If there are studs that do not align with a mounting hole on the motherboard, it is recommended that you remove that stud to prevent the possibility of a short circuit. In most cases, it is recommended to secure the motherboard using a minimum of nine (9) spacers and screws.

1. Carefully place the motherboard onto the stand offs located inside the chassis.
2. Align the mounting holes with the stand offs.
3. Align the connectors to the I/O shield.
4. Ensure that the fan assembly is aligned with the chassis vents according to the fan assembly instruction.
5. Secure the motherboard with a recommended minimum of nine (9) screws.

Connecting Cables

This section takes you through all the necessary connections on the motherboard. This will include:

- ❑ Power Connections
 - 24-pin ATX power (**PW1**)
 - 8-pin ATX 12V power (**PW12**)
- ❑ Internal Headers
 - Front panel
 - IEEE 1394a
 - USB Headers
 - Audio
- ❑ IDE
- ❑ Serial ATA II
- ❑ USB 2.0
- ❑ Expansion slots
- ❑ CMOS Clear Button

24-pin ATX Power (PW1)


PW1 is the main power supply connector located along the edge of the board next to the DIMM slots. Make sure that the power supply cable and pins are properly aligned with the connector on the motherboard. Firmly plug the power supply cable into the connector and make sure it is secure.



PW1 connector
Plug power cable from system power supply to PW1

Figure 1. PW1 Motherboard Connector

Table 1. PW1 Pin Assignments

| Connector | Pin | Signal | Pin | Signal |
|--|-----|---------|-----|--------|
|  | 1 | +3.3V | 13 | +3.3V |
| | 2 | +3.3V | 14 | -12V |
| | 3 | GND | 15 | GND |
| | 4 | +5V | 16 | PS_ON |
| | 5 | GND | 17 | GND |
| | 6 | +5V | 18 | GND |
| | 7 | GND | 19 | GND |
| | 8 | PWROK | 20 | RSVD |
| | 9 | +5V_AUX | 21 | +5V |
| | 10 | +12V | 22 | +5V |
| | 11 | +12V | 23 | +5V |
| | 12 | +3.3V | 24 | GND |

8-pin ATX 12V Power (PW12)

PW12, the 8-pin ATX 12V power connection, is used to provide power to the CPU. Align the pins to the connector and press firmly until seated.

Connecting IDE Hard Disk Drives

The IDE connector supports Ultra ATA 133/100/66 IDE hard disk drives.

1. Connect the blue connector (the cable end with a single connector) to the motherboard.
2. Connect the black connector (the cable with the two closely spaced black and gray connectors) to the Ultra ATA master device.
3. Connect the gray connector to a slave device.

If you install two hard disk drives, you must configure the second drive as a slave device by setting its jumper accordingly. Refer to the hard disk documentation for the jumper settings.

If an ATA-66/100 disk drive and a disk drive using any other IDE transfer protocol are attached to the same cable, the maximum transfer rate between the drives may be reduced to that of the slowest drive.

